

# ATTENTION: Read before installation!

Attention: special instructions installing EVO AC® films

**EVO AC® is a new range of anti-dripping greenhouse films based on a 8-layer technology. A real EVOLution in Anti-Condensation performance.**

Films equipped with EVO AC® permanent AntiDrip and AntiFog do have special coating on the surface. This coating is located on the surface of the film (as shown below).



We advise strongly to follow the below instructions to avoid damaging the film and potentially losing the warranty:

- Use protection tape for all metal parts of the construction to avoid scratches
- During installation it is imperative not to scratch the film's anti-dripping surface on the structure or the supporting wires.
- After installation you must be able to read the printing „this side inside“ correctly from the inside the greenhouse.
- Rewind the film only with suitable equipment / rewinding bars.
- Do not fold film rather roll onto paper/plastic cores.
- Avoid folds, they can destroy the special AntiDrip coating. Good tension of the installed film required.
- It may take 4-6 weeks after exposure and certain level of humidity till the AntiDrip/AntiFog obtains its entire effect.

